



September 2016

Anti-Scratch varnish AE 12 Technical data sheet

Product name: **AE 12**

Code: **168712**

1. General

The AE 12 varnish is a polysiloxane-based flexible coating protecting against the effects of scratching and abrasion. It is suitable for the coating of POLYAMIDES (e.g. Trogamid®), POLYCARBONATES and CR 39®.

AE 12 is used without primer treatment. It can be applied by a variety of techniques followed by a cure cycle at about 75 min at 120°C or 3 h à 80°C for full reticulation. This varnish is tintable with usual dyes.

2. Properties

Aspect	Colourless liquid
Content	29-31% (according to ISOCHEM specifications)
Density at 20°C	~ 0.95 (according to ISOCHEM specifications)
Viscosity at 20°C	~ 37 s. (11 mP.s - AFNOR T 30014 Cup n°2.5 – according to ISOCHEM specifications)
Shelf life*	8 months at -20 ±5 °C 4 months at +5 ±3 ° C 6 weeks at+20 ±5 °C
Flash point	21°C
pH (20°C)	~ 5 (according to ISOCHEM specifications)
Solvents	Ethanol (96%), Eau (3%), Toluene (1% to denaturate ethanol)

^(*) from production date and including transportation at room temperature

3. Application techniques:

- Dip,
- · Flow-coating,
- Spray,
- Rotation.





September 2016

4. Application process

Working place:

- Properly ventilated area
- Dust free
- Relative humidity of 30 to 50%

Preparation of the area to coat:

- Wash with a detergent solution in order to get rid of dust, fats or residue of protection
- Ultrasonic cleaning is necessary

Application:

Varnish temperature 15-20°CVarnish filtration 1 micron

Dust-free drying
 Curing
 5 min at 70°C in infrared channel
 120 min at 100°C (Polyamide)
 75 min at 120°C (Polycarbonate)

Cleaning:

- Current cleaning : wash with ethanol

- Deep cleaning: wash with 1% aqueous caustic soda

5. Concentration adjustment

- With ethanol

6. Coating performance

Aspect	Clear and transparent
Refractive Index	1.5
Bayer-test	4
Colorability	Trogamid®: Excellent, Grilamid®: a primer is necessary
Adhesion	Excellent: no delamination after immersion for 30 min in boiling water

7. Packaging

1L sample and 5 kg: HDPE Jerrycan - Other upon request

8. Contact

Jean-Claude BRUYÈRE mail: jeanclaude@bruyere-pirot.com

Tél. +33 1 43 46 53 56 Mob. +33 6 82 82 05 13

The content and data presented are provided purely for information and guidance.

Controls and tests are necessary before use